

Refill Instructions for HP CN045A, CN046A, CN047A, CN048A

Preparation:

1. Remove cartridge from printer and stand it on the end with the plastic ball facing up (Figure 1).
2. Push the ball into the cartridge, using the "Black Entry Tool" provided.



Figure 1

Refill:

3. Prepare the syringe by putting the Needle on it.
4. Charge your syringe by drawing 10cc of ink out of the correct ink bottle.

5. Fill the cartridge through the hole created by pushing the ball in, as shown on the left. DO NOT OVER FILL. If the cartridge was empty, it will take about 40 cc of ink to fill the high capacity black and 20 cc of ink to fill the high capacity color cartridges.
6. When the filling operation is complete, squeeze the sides of the cartridge tightly. While holding the sides, insert a new ball into the Fill Hole and press it in with the Black Tool. (You should pull out the plug for subsequent refills.)
7. Finally, disable the ink status monitor on the printer. The process varies by model:
 - a. OfficeJet Pro 8100
 - i. Press and hold the Wireless and Resume Buttons
 - ii. The Ink icons will blink four times
 - iii. Press and hold the Wireless and Resume Buttons Again
 - b. Officejet Pro 8600
 - i. Touch the right Arrow and Setup
 - ii. Select Preferences and then select Cartridge/Chip Information
 - iii. Touch OK to turn off the monitor